

What is the self-ignition temperature?

The energy required to start a flame can be changed to thermal form by an increase in the temperature of the mixture. The self-ignition temperature is the minimum temperature at which an explosive atmosphere can spontaneously ignite.